FTA750 Full Voltage Starting Limited Service Electric Fire Pump Controllers **Product Description**



Description—Firetrol® FTA750 Limited Service Controllers are intended for use with small electric motor driven fire pumps where the capacity of the power source permits full voltage starting. Full voltage is applied to the motor as soon as the controller is actuated. The controller monitors, displays and records fire pump system information.

Limited Service Controllers may be used where they are acceptable to the authority having jurisdiction.

Approvals – Firetrol fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, and CSA, Standard for Industrial Control Equipment. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

Standard Features—The following are included as standard with each controller:

- Voltage surge protector
- Main Thermal-Magnetic circuit breaker for assigned horsepower and voltage
- Motor contactor
- **Emergency Manual Run Mechanism to mechanically** close motor contactor contacts in an emergency condition
- Built-in Start and Stop push-buttons to bypass automatic start circuits
- Minimum Run Timer / Off Delay Timer
- ٠ Daylight Savings Time Option
- Weekly Test Timer ٠
- **Elapsed** Time Meter

- Door mounted display/interface panel featuring a 128 x 64 pixel backlit LCD Graphical Display, Membrane Type User Control Push-buttons and easy to read LED Indicators for:
 - POWER AVAILABLE
 - ALARM
 - TRANSFER SWITCH NORMAL (If unit ordered with Automatic Power Transfer Switch)
 - TRANSFER SWITCH EMERGENCY (If unit ordered with Automatic Power Transfer Switch)
 - SYSTEM PRESSURE LOW
 - PUMP RUNNING
 - DELUGE OPEN
 - REMOTE START
 - INTERLOCK ON
 - FAIL TO START
 - MOTOR OVERLOAD
 - EMERGENCY ISO SWITCH OFF (If unit ordered with Automatic Power Transfer Switch)
 - PHASE FAILURE
 - PHASE REVERSAL
 - AUTOMATIC SHUTDOWN DISABLED
 - OVERVOLTAGE
- UNDERVOLTAGE
- **Digital Pressure Display**
- USB Host Controller and Port
- Solid State Pressure Transducer
- Data Log
- Event Log (3000 Events)
- True RMS Metering with simultaneous 3 Phase Display of Amps, Volts, Frequency, Pressure and Alarm Messages
- Disk Error message Disk Near Full message •
- Pressure Error message •
- Motor Over 320% message
- Local Start message
- Remote Start message
- Emergency Start message
- Fail To Start message
- Undervoltage message •
- Overvoltage message
- NEMA Type 2 enclosure (IEC IP22) •
- Suitable for use as Service Equipment
- Each standard controller comes with user configurable options for:
 - Interlock Alarm
 Low Pressure Audible
 - Low Suction Pump Run
 - User Defined Input
 Weekly Test





SPECIAL ENCLOSURES

- -Т
- NEMA Type 3R (IEC IP22), Painted Steel NEMA Type 4 (IEC IP66), Painted Steel NEMA Type 4X (IEC IP66), #304 Stainless Steel, -È -F
- Unfinished*
- -FXP NEMA Type 4X (IEC IP66), #304 Stainless Steel, Painted Finish
- NEMA Type 4X (IEC IP66), #316 Stainless Steel, Unfinished** -FD
- NEMA Type 4X (IEC IP66), 12 Gauge, Seam Welded, #316 Stainless Steel, Polished and -FDB Brushed Finish
- -FDP NEMA Type 4X (IEC IP66), #316 Stainless Steel Painted Finish
- -G NEMA Type 12 (IEC IP54), Painted Steel ** Unfinished (Not painted, polished or brushed).

CIRCUIT BREAKER OPTION

- Intermediate withstand rating
 - 85,000 Amperes RMS Sym. at 200-240V 65,000 Amperes RMS Sym. at 380-480V 25,000 Amperes RMS Sym. at 550-600V

ANTI-CONDENSATION SPACE HEATERS

- 120 Volt Space Heater 120 Volt Space Heater With Thermostat -H
- -| -k
- 120 Volt Space Heater With Humidistat -L 240 Volt Space Heater
- -M 240 Volt Space Heater With Thermostat
- -N 240 Volt Space Heater With Humidistat

- PRESSURE TRANSDUCERS -B 0-600 psi (0-42.25 bar) Pressure Transducer for Fresh Water Service
- 0-300 psi (0-21.1 bar) Pressure Transducer for -C Copper Corrosive Service 0-600 psi (0-42.25 bar) Pressure Transducer for
- -D Copper Corrosive Service

COMBINED AUTOMATIC POWER TRANSFER SWITCHES

FTA976 - For use with generator set/second utility emergency source

ALARMS

- Extra contacts (normally open & normally closed) for -AC remote indication, pump operating
- -AF Audible and Visible low pump room temperature alarm
- -AG Audible and Visible reservoir low alarm
- Audible and Visible low suction pressure alarm Contacts for remote indication, pump fail to start -AH
- -AM
- Contacts for remote indication, low pump room temperature (Requires option -AF) Contacts for remote indication, reservoir -AV -AW
- low (Requires option -AG) Contacts for remote indication, low suction pressure (Re--AY quires option -AH)
- -AZ Low pump room temperature switch, mounted and wired -BW Extra contacts for remote indication, phase failure/phase reversal

Emerson Network Power - Global Headquarters

1050 Dearborn Drive Columbus, OH 43085 Tel +1 614 888 0246

EmersonNetworkPower.com

- Contacts for remote indication, pump overload -BY
- Low Suction Pressure Alarm, (Includes selectable auto/ manual reset, audible, visible and remote alarms, initiating -COM pressure switch NOT included) -CTS
- Built-in Low Suction Pressure Álarm Panel (Includes selectable auto/manual reset, audible, visible and remote alarms and wired and mounted pressure switch)
- -EG Audible and Visible relief valve discharge alarm -ĒH Contacts for remote indication, relief valve discharge (Requires option -EG)
- -EJ -EK Audible and Visible flow meter on alarm
- Contacts for remote indication, flow meter on (Requires option -EI) -KH
- Contacts for remote indication, common output for any alarm
- -JR -JT -P
- Visible jockey pump running indication Audible and Visible jockey pump trouble indication Built-in alarm system (includes visible supervisory voltage normal indication and audible pump operating, phase failure and phase reversal indication)
- -PE Contacts for remote indication, low system pressure (pump on demand)
- Built-in alarm system, 220 VAC supervisory power (Includes visible supervisory voltage normal indication and audible pump operating, phase failure and phase reversal -PT indication)

MISCELLANEOUS

- Load shed circuits (Selectable power source and adjustable time delay to remove non-critical loads before starting) Series pumping, high zone controller -ED
- -EL
- -EM
- -EN
- Series pumping, nigh zone controller Series pumping, low zone controller(s) Series pumping, low zone controller 400 VAC Operation (Controller labeled for operation at 380-400 VAC Use with voltage code FZ) -FZX -IFC
- CE Marking with Externally Mounted Wet Parts CE Marking with Internally Mounted Wet Parts OSHPD Seismic Certification (State of California) (Requires -IFCI -OSP
- Option -SEI) -PY Motor space heater output contacts
- Tropicalization
- -S -SEI Seismic Certification (in accordance with IBC)
- (Note: Not available on model FTA1500)
- -USBX Èxternal USB Port
- Customized, annual service display message (when factory programmed or programmed by Firetrol representative -7PA
- during start-up) -ZPN Serial Modbus RTU over Ethernet TCP/IP using 5150 Connectivity Module
- -ZPM Serial Modbus RTU over 2-wire or 4-wire RS485

Export packaging (Wooden crating to conform to IPPC Standards)

*Weekly Test Timer - Standard

ASCO Power Technologies - Firetrol Brand Products

111 Corning Road, Suite 120 Cary, NC 27518 Tel +1 919 460 5200 • Fax +1 919 460 5250

Firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, ASCO assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Information and specifications are subject to change without notice. Emerson, Consider It Solved., Emerson Network Power, the Emerson Network Power Logo, ASCO, Firetrol and the Firetrol Logo are trademarks or registered trademarks of Emerson Electric Co. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. ©2014 Emerson Electric Co. PD750-50 (E)

EMERSON. CONSIDER IT SOLVED