



- ① OPERATIONAL INTERFACE PANEL
- ② E-STOP PUSHBUTTON
- ③ DISCONNECTING MEANS HANDLE
- ④ EMERGENCY START HANDLE
- ⑤ PRESSURE TRANSDUCER
- ⑥ TEST VALVE DRAIN
- ⑦ SUCTION TRANSDUCER (OPTIONAL)

467000-0001
REVISIONS
A: RELEASED PER ECN E00787.12/10/10