FTA740 SINGLE PHASE LIMITED SERVICE CONTROLLERS WITH POWER TRANSFER SWITCH

STANDARD SUBMITTAL PACKAGE



NOTE: The drawings included herein are for standard controllers. Actual "as built" drawings may differ from those seen here.



SBP740-61

FTA740 Single Phase Limited Service Electric Fire Pump Controllers Product Description



Description—Firetrol[®] FTA740 Single Phase Limited Service Controllers are intended for use with small electric motor driven fire pumps where the capacity of the power source permits full voltage starting. Full voltage is applied to the motor as soon as the controller is actuated. The controller monitors, displays and records fire pump system information.

Limited Service Controllers may be used where they are acceptable to the authority having jurisdiction.

Approvals – Firetrol[®] fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, and CSA, Standard for Industrial Control Equipment. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

Standard Features—The following are included as standard with each controller:

- Voltage surge protector
- Main Thermal-Magnetic circuit breaker for assigned horsepower and voltage
- Motor contactor
- Emergency Manual Run Mechanism to mechanically close motor contactor contacts in an emergency condition
- Built-in Start and Stop push-buttons to bypass automatic start circuits
- Minimum Run Timer / Off Delay Timer
- Daylight Savings Time Option
- Weekly Test Timer
- Elapsed Time Meter

- Door mounted display/interface panel featuring a 128 x 64 pixel backlit LCD Graphical Display, Membrane Type User Control Push-buttons and easy to read LED Indicators for:
 - POWER AVAILABLE
 - ALARM
 - TRANSFER SWITCH NORMAL (If unit ordered with Automatic Power Transfer Switch)
 - TRANSFER SWITCH EMERGENCY (If unit ordered with Automatic Power Transfer Switch)
 - SYSTEM PRESSURE LOW
 - PUMP RUNNING
 - DELUGE OPEN
 - REMOTE START
 - INTERLOCK ON
 - FAIL TO START
 - MOTOR OVERLOAD
 - EMERGENCY ISO SWITCH OFF (If unit ordered with Automatic Power Transfer Switch)
 - AUTOMATIC SHUTDOWN DISABLED
 - OVERVOLTAGE
 - UNDERVOLTAGE
- Digital Pressure Display
- USB Host Controller and Port
- Solid State Pressure Transducer
- Data Log
- Event Log (3000 Events)
- True RMS Metering with Display of Amps, Volts, Frequency, Pressure and Alarm Messages
- Disk Error message
- Disk Near Full message
- Pressure Error message
- Motor Over 320% message
- Local Start message
- Remote Start message
- Emergency Start message
- Fail To Start message
- Undervoltage message
- Overvoltage message
- NEMA Type 2 enclosure (IEC IP22)
- Suitable for use as Service Equipment
- Each standard controller comes with user set options for:
 - Interlock Alarm Low Pressure Audible
 - Low Suction Pump Run
 - User Defined Input
 Weekly Test





FTA976 Power Transfer Switch for Limited Service Electric Fire Pump Controllers - Product Description



Description—Firetrol® Power Transfer Switches are available completely assembled with Firetrol Limited Service Electric Fire Pump Controllers. The power transfer switches are built for use with generator set or 2nd utility use. The entire package of power transfer switch and controller is completely factory assembled, wired, tested and shipped as a complete unit for easy field connection to the power sources and the fire pump motor. They are available for 3 phase or single phase operation.

Approvals—Firetrol power transfer switches are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers; UL1008, Automatic Transfer Switches; UL508, Industrial Control Equipment and CSA, Standard for Industrial Control Equipment. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

Standard Features—The following are included as standard with each transfer switch:

- Thermal magnetic circuit breaker
- 3-pole, double throw transfer switch mechanism, electrically operated, mechanically held

- ASCO[®] Group 5 Control module providing for the following:
 - -Door mounted operator interface panel with 4 line LCD display
 - -In-phase monitor (3 phase operation)
 - -Programmable engine exerciser
 - -Transfer switch data logging
 - -Differential voltage sensing on all phases of the normal power source
 - -Voltage sensing of the emergency power source
 - -Frequency sensing of the emergency power source
 - -Transfer time delay to compensate for momentary power outages of the normal source
 - Retransfer from emergency to normal source is automatically delayed unless the emergency source fails
 Cool-down timer for unloaded running of the generator set after retransfer to the normal power source
 - -Instantaneous retransfer to normal if the emergency source fails and the normal source is available
 - -3 second transfer restart delay to reduce current surges when transferring to or from the emergency source
 - -NO and NC engine control contacts to start the generator set when the normal power source fails
- Transfer Switch Normal LED
- Transfer Switch Emergency LED
- Emergency Isolating Switch Open LED
- Test Selector Switch
- Transfer By-pass Switch
- Silence Alarm Push-button
- Emergency Isolating Switch Open and Transfer Switch in Emergency Audible Alarms
- Output contacts (NO and NC) for Generator Start, Emergency Isolating Switch Open and Transfer Switch position indicators
- NEMA Type 2 enclosure (IEC IP22)





Main Fire Pump Controller

The main fire pump controller shall be a factory assembled, wired and tested unit and shall conform to all the requirements of the latest edition of NFPA 20, Standard for the Installation of Stationary Pumps for Fire Protection and NFPA 70, National Electrical Code.

The controller shall be listed by Underwriters Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, CSA, and Canadian Standards Association CSA-C22.2, Standard for Industrial Control Equipment (cULus).

Starting Method

The controller shall be of the combined manual and automatic type designed for full voltage starting of the fire pump motor having the horsepower, voltage, phase and frequency rating shown on the plans and drawings. The controller com-ponents shall be housed in a NEMA Type 2 (IEC IP22) drip-proof, wall mounted enclosure.

Withstand Ratings (Short Circuit Current Ratings)

All controller components shall be front mounted, wired and front accessible for maintenance. The minimum withstand rating of the controller shall not be less than:

10,000 Amperes RMS Sym. at 200-240V

If the available fault current of the system exceeds these ratings, the controller shall be available with a withstand rating as shown below:

65,000 Amperes RMS Sym. at 200-240V

Circuit Breaker

The controller shall include a thermal magnetic circuit breaker. The circuit breaker shall be mechanically interlocked so that the enclosure door cannot be opened with the handle in the ON position except by a hidden tool operated bypass mechanism. The circuit breaker shall be capable of being padlocked in the OFF position for installation and maintenance safety, and shall also be capable of being locked in the ON position without affecting the tripping characteristics of the circuit breaker. The controller door shall have a locking type handle and three point cam and roller vault type hardware. The controller shall be suitable for use as service equipment.

Operator Interface

The fire pump controller shall feature an operator interface with user keypad. The interface shall monitor and display motor operating conditions, including all alarms, events, and pressure conditions. All alarms, events, and pressure conditions shall be displayed with a time and date stamp. The display shall be a 128x64 Backlit LCD capable of customized graphics. The display and interface shall be NEMA rated for Type 2, 3R, 4, 4X, and 12 protection and shall be fully accessible without opening the controller door. The display and user interface shall utilize multiple levels of password protection for system security. A minimum of 3 password levels shall be provided.

Ammeter/Voltmeter

The fire pump controller operator interface shall be capable of displaying true RMS digital motor voltage and current measurements. Displays requiring push-button and selector switches to toggle between phases or current and voltage shall not be accepted.

Voltage and current shall be measured by True RMS technology to provide the most accurate measurement for all sine waves, including non-sinusoidal waveforms. Average responding meters will not be accepted.

Digital Status/Alarm Messages

The digital display shall indicate text messages for the status and alarm conditions of: Sequential Start Time

- Motor On Minimum Run Time
- / Off Delay Time
- Fail to Start
- Under Voltage
- Locked Rotor Trip
- Emergency Start •
- Drive Not Installed
- Disk Error Disk Near Full
- Motor Overload Printer Error Pressure Error

Local Start

Remote Start

Óver Voltage

Over Frequency

• Motor Over 320%

System Battery Low

- The Sequential Start Timer and Minimum Run Timer/Off Delay Timer shall be displayed as numeric values reflecting the value of the remaining time.

LED Visual Indicators

LED indicators, visible with the door closed, shall indicate[•]

- Power Available Alarm
 - Pump Running System Pressure Low

Fail To Start

- Remote Start Transfer Switch Normal
- Deluge Open . Transfer Switch Emergency
- Interlock On
 - Motor Overload • Emerg. Iso. Switch Off
- Automatic Shutdown Disabled
- Overvoltage Undervoltage

Data Logging

The digital display shall monitor the system and log the following data: Motor Calls/Starts

- Pump Total Run TimeTotal Controller Pwr On Time

Max Starting Currents

- Last Pump Start • Min/Max System Pressure Last Locked Rotor Current
- Pump Last Run Time Last Locked Rotor Trip
- Min/Max Frequency
- Max Run Currents
- Min/Max Voltage per Phase while idle (not running) Min Voltage per Phase during Start Min/Max Voltage per Phase during Run





Event Recording

Memory - The controller shall record all operational and alarm events to system memory. All events shall be time and date stamped and include an index number. The system memory shall have the capability of storing 3000 events and allow the user access to the event log via the user interface. The user shall have the ability to scroll through the stored messages in groups of 1 or 10.

USB Host Controller

The controller shall have a built-in USB Host Controller. A USB port capable of accepting a USB Flash Memory Disk shall be provided. The controller shall save all operational and alarm events to the flash memory on a daily basis. Each saved event shall be time and date stamped. The total amount of historical data saved shall solely depend on the size of the flash disk utilized. The controller shall have the capability to save settings and values to the flash disk on demand via the user interface.

Serial Communications

The controller shall feature a RS485 serial communications port for use with 2 or 4 wire Modbus RTU communications.

Solid State Pressure Transducer

The controller shall be supplied with a solid state pressure transducer with a range of 0-300 psi (0-20.7 bar) ±1 psi. The solid state pressure switch shall be used for both display of the system pressure and control of the fire pump controller. Systems using analog pressure devices or mercury switches for operational control will not be accepted. The START, STOP and SYSTEM PRESSURE shall be digi-

The START, STOP and SYSTEM PRESSURE shall be digitally displayed and adjustable through the user interface. The pressure transducer shall be mounted inside the controller to prevent accidental damage. The pressure transducer shall be directly pipe mounted to a bulkhead pipe coupling without any other supporting members. Field connections shall be made externally at the controller coupling to prevent distortion of the pressure switch element and mechanism.

Seismic Certification

The controller shall be certified to meet or exceed the requirements of the 2006 International Building Code and

the 2010 California Building Code for Importance Factor 1.5 Electrical Equipment for Sds equal to 1.88 or less severe seismic regions. Qualifications shall be based upon successful tri-axial shake-table testing in accordance with ICC-ES AC-156. Certification without testing shall be unacceptable. Controller shall be clearly labeled as rated for installation in seismic areas and a Certificate of Conformance shall be provided with the controller.

Operation

A digitally set On Delay (Sequential Start) timer shall be provided as standard. Upon a call to start, the user interface shall display a message indicating the remaining time value of the On Delay timer.

The controller shall be field programmable for manual stop or automatic stop. If set for automatic stopping, the controller shall allow the user to select either a Minimum Run Timer or an Off Delay Timer. Both timers shall be programmable through the user interface.

A nonadjustable restart delay timer shall be provided to allow the residual voltage of the motor to decay prior to restarting the motor. At least 2 seconds, but no more than 3 seconds, shall elapse between stopping and restarting the pump motor.

A weekly test timer shall be provided as standard. The controller shall have the ability to program the time, date, and frequency of the weekly test. In addition, the controller shall have the capability to display a preventative maintenance message for a service inspection. The message text and frequency of occurrence shall be programmable through the user interface.

A Lamp Test feature shall be included. The user interface shall also have the ability to display the status of the system inputs and outputs.

A Audible Test feature shall be included to test the operation of the audible alarm device.

The fire pump controller software shall be automatically upgradable through the USB port by simply inserting a flash disk with the new software. Fire pump controllers that require laptop computers, handheld equipment or specialized devices for software upgrades shall be prohibited.

The controller shall be a Firetrol brand.

Emerson Network Power - Global Headquarters

1050 Dearborn Drive Columbus, OH 43085 Tel +1 614 888 0246

ASCO Power Technologies - Firetrol Brand Products

111 Corning Road, Suite 120 Cary, NC 27518 Tel +1 919 460 5200 • Fax +1 919 460 5250

EmersonNetworkPower.com

Firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, ASCO assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Information and specifications are subject to change without notice. Emerson, Consider It Solved., Emerson Network Power, the Emerson Network Power Logo, ASCO, Firetrol and the Firetrol Logo are trademarks or registered trademarks of Emerson Electric Co. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. ©2013 Emerson Electric Co. SP740-50

EMERSON. CONSIDER IT SOLVED

Main Fire Pump Controller with Transfer Switch

The main fire pump controller shall be factory assembled and wired with a power transfer switch listed by Underwriters' Laboratories, Inc. for transfer switch and fire pump service.

The power transfer switch and fire pump controller shall be factory assembled, wired and tested as a single unit and shall conform to all requirements of the latest edition of NFPA 20, *Centrifugal Fire Pumps* and NFPA 70, *National Electrical Code*.

Power Transfer Switch for Gen Set / Second Utility Emergency Power Source

The power transfer switch shall be housed within the fire pump controller enclosure or in a NEMA Type 2 (IEC IP22) drip-proof enclosure attached directly to the fire pump controller. Where the power transfer switch is provided in an attached enclosure, the enclosures shall be fitted so that the assembly constitutes a single unit. The fire pump controller/power transfer switch shall be factory assembled, wired and tested as a unit prior to shipment.

The power transfer switch shall include a motor rated circuit breaker, operated with a single, externally mounted handle. The circuit breaker shall be mechanically interlocked so that the enclosure door cannot be opened with the handle in the ON position except by a hidden tool operated bypass mechanism. The circuit breaker shall be capable of being padlocked in the OFF position for installation and maintenance safety, and shall also be capable of being locked in the ON position without affecting the tripping characteristics of the circuit breaker. The enclosure door shall have a locking type handle and three point cam and roller type vault hardware.

The fire pump controller/power transfer switch shall have data logging capability for historical operation recording and to aid in annual test, service and trouble shooting. The data logging shall be accessible by front mounted interface panel and also by saving the information via the standard USB port. The data file shall be in text (.txt) format and easily readable by most common text editing or word processing software.

The automatic transfer switch shall consist of an inherently double throw power transfer switch mechanism and a microprocessor control panel to provide automatic operation. The transfer switch and control panel shall be of the same manufacturer. The automatic transfer switch shall be an ASCO 7000 series with a group 5 control panel.

The transfer switch shall be electrically operated and mechanically held. The electrical operator shall be a momentarily energized, single solenoid mechanism. The switch shall be mechanically interlocked to ensure only two possible positions, normal or emergency. Switches having a neutral position shall not be permitted.

The switch shall be positively locked and unaffected by momentary outages, so that contact pressure is maintained at a constant value and contact temperature rise is minimized for maximum reliability and operating life. All main contacts shall be silver composition and inspection of all contacts shall be possible from the front of the switch without disassembly of operating linkages and without disconnection of power.

Designs utilizing components of molded case circuit breakers, contactors, or parts thereof, which are not intended for continuous duty, repetitive switching or transfer between two active power sources are not acceptable.

The transfer switch control panel shall have a 4 line, 20 character LCD display and keypad for viewing all available data and setting desired operational parameters. Voltage and frequency on both the normal and emergency sources





shall be continuously monitored. The normal source pick up shall be set at 95% of nominal voltage and the emergency source pick up set at 90% of nominal voltage and 95% nominal frequency. Source status screens shall be provided for both normal & emergency to provide digital readout of voltage, frequency and phase rotation on all 3 phases. The transfer shall also be available configured for use with single phase limited service controllers.

The transfer switch shall have visible pilot light indication for the following conditions: TRANSFER SWITCH IN NORMAL, TRANSFER SWITCH IN EMERGENCY, NORMAL SOURCE ACCEPTED, EMERGENCY SOURCE ACCEPTED and EMERGENCY ISOLATION SWITCH OPEN. Remote alarm contacts shall be supplied as standard for the following conditions: EMER-GENCY SOURCE ISOLATION SWITCH OPEN, NORMAL POWER AVAILABLE, EMERGENCY POWER AVAILABLE and TRANSFER SWITCH POSITION. An audible alarm shall sound if: EMERGENCY ISOLATION SWITCH OPEN and TRANSFER SWITCH IN EMERGENCY. A SILENCE ALARM push-button shall be supplied. A selector switch shall be supplied to manually test the transfer to emergency and the retransfer to normal power.

The transfer switch shall be a Firetrol FTA976 for generator set and second utility emergency power.

Note: FTA976 power transfer switches are designed for use with Firetrol Limited Service Electric Fire Pump Controllers.


Emerson Network Power - Global Headquarters 1050 Dearborn Drive Columbus, OH 43085 Tel +1 614 888 0246 ASCO Power Technologies - Firetrol Brand Products 111 Corning Road, Suite 120 Cary, NC 27518 Tel +1 919 460 5200 • Fax +1 919 460 5250


EmersonNetworkPower.com


Firetrol.com


While every precaution has been taken to ensure accuracy and completeness herein, ASCO assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Information and specifications are subject to change without notice. Emerson, Consider It Solved., Emerson Network Power, the Emerson Network Power Logo, ASCO, Firetrol and the Firetrol Logo are trademarks or registered trademarks of Emerson Electric Co. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. ©2013 Emerson Electric Co. SP976-50 (A)

EMERSON. CONSIDER IT SOLVED^{**}









BLOCKS

69

68

68

67

66

22

21

20

19

19

NORMALLY OPEN,

TO EMERGENCY SOURCE

ISOLATING SWITCH

OPEN REMOTE

ALARM CIRCUITS

TO PUMP

OPERATING REMOTE

ALARM CIRCUITS

TO POWER/PHASE FAILURE REMOTE

ALARM CIRCUITS

CLOSES TO ALARM

NORMALLY CLOSED, OPENS TO ALARM

NORMALLY CLOSED, OPENS TO ALARM

NORMALLY OPEN.

NORMALLY OPEN

PRESSURE SYSTEM

CONNECTION 1/2" FNPT

CLOSES TO ALARM

SEE NOTE

SEE NOTE

21CR

21CR

И

1M

1M

4CR


NOTES

- Incoming line terminals are provided to accommodate wire sizes at 125% of motor full load current per NFPA 70, *National Electrical Code*, Table 430-248, Section 695.6(c), 1and Table 310-16, 75' rated Copper conductors.
- 2- Motor connections shown are typical. Since motor connections vary widely, refer to the motor connection diagram for specific wiring arrangement.

SPARE TERMINALS PROVIDED FOR PARALLEL CONNECTION OF REMOTE ALARMS (IF REQUIRED) ⚠


TERMINALS FOR CUSTOMER CONNECTIONS REQUIRE 3.5MM SLOTTED SCREW DRIVER NOTE:

TERMINAL TIGHTENING TORQUE								
TERMINAL TYPE	WIRE SIZE	TIGHTENING TORQUE						
CONTROL AND ALARM TERMINALS	#14-12 AWG [2.5-4 MM ²]	5.6 lb—in [.6 Nm]						



PROJECT	NAME	:					REV. TO SHEET	ECN	NO.	BY	APP.	DATE
FIELD CONNECTIONS FTA740 WITH FTA976 SINGLE PHASE LIMITED SERVICE CONTROLLER WITH POWER TR							'RANSFER			THIRD ANGLE PROJECTION		
SWITCH	BY	DATE	MANUFACTURING TOLERANCE ACCORDANCE WITH ASCO PROC	EDURE MP-I-00	03.		Сом	PUTE	R GEN			RAWING
DRAWN BY CHECKED	TEF	06/04/13	PROPERTY OF ASCO POWER	PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR			SCALE 1:1 SIZE			А		
PROJECT APPROVAL FINAL	TEF	06/04/13		DESIGN OR INV			ржд. но. FC7	<u>40-</u>		<u> </u>		
APPROVAL							DRAWING . REV.	- E	°.24	275	SHEET 1 OF 1	

Firetrol[®]



NOTE

Incoming line terminals are provided to accomodate wire sizes at 125% of motor full load current per NFPA 70, *National Electrical Code*, Table 430-248, Section 695.6(c), and Table 310-16, 75° rated Copper conductors.

LINE TERMINALS-WIRE CAPACITY AND QUANTITY (CU) $\langle 1 \rangle$

MAXIMUM MOTOR HORSEPOWER	WIRE SIZE (CU)	WIRE SIZE
200-240V	PER` PHASE	GROUND LUG (CU)
15	(1) #14 AWG-#1/0 AWG (1) 2.5 MM ² - 50 MM ²	(2) #14 AWG-#2/0 AWG (2) 2.5 MM ² - 70 MM ²

FOR CORRECT WIRE SIZING, REFER TO **NATIONAL ELECTRICAL CODE**, NFPA 70. $\langle 1 \rangle$

62	63	70	71	81	82	83	84		
NORMALLY NORMALLY CLOSED OPEN -OPENS -CLOSES TO START TO START ENGINE ENGINE				CONTACT CONTACT OPEN WHEN CLOSED WHEI TRANSFER TRANSFER SWITCH IS SWITCH IS IN NORMAL, IN NORMAL, CLOSED -OPENS WHEN IN WHEN IN EMERGENCY EMERGENCY					
				`					
ENGINE START CONTACTS				TRANSFER SWITCH POSITION INDICATOR CONTACTS FOR REMOTE ALARM CIRCUITS					

CONTROL AND ALARM TERMINAL BLOCKS

NOTE: CONTROL AND ALARM TERMINALS FOR CUSTOMER CONNECTIONS REQUIRE 3.5MM SLOTTED SCREW DRIVER

-NOTE-
ENGINE START
CONTACT RATING
1/2 AMP, 30VDC
., ,

Firetrol[®]

TERMINAL TIGHTENING TORQUE							
TERMINAL TYPE	WIRE SIZE	TIGHTENING TORQUE					
CONTROL AND ALARM TERMINALS	#14-12 AWG [2.5-4 MM ²]	7.1 lb—in [.8 Nm]					

-NOTE-
ALARM CONTACT
RATING
PILOT DUTY
240 VAC, 28 VDC
5 AMP MAX. LOAD

PROJECT	PROJECT NAME:							NO. B	Y AP	P. DATE	
FIELD CONNECTIONS				FTA976							
			CONTROLLER POWER			R GEN-	-SET		THIRD ANGLE		
AND SE	CON		TY POWER SOURCE		HASE)				PROL	JECTION	
	BY	DATE	MANUFACTURING TOLERANCE ACCORDANCE WITH ASCO PROCI			COMPUTER GENERATE				DRAWING	
DRAWN BY	TEF	06/04/13	FOR PLASTIC PARTS SEE		ASSEM. REF. NO.					DRAWING	
CHECKED			PROPERTY OF ASCO POWER	PROPERTY OF ASCO POWER TECHNOLOGIES, USE PERMITTED FOR OUR			1:1	size A			
PROJECT			WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED. DWG. NO.								
FINAL	TEF	06/04/13		RCOO [®] ASCO Power Technologies, Lp.				<u>FC976-56</u>			
APPROVAL				HAM PARK, NEW JERS	SEY 07932 U.S.A.	DRAWING	- EC!	2427	752	SHEET 1 OF 1	